

Hanging Instructions for Wallcovering

Coated Textile Wallpaper

untrimmed

1. SURFACE PREPARATION

- Apply a high-quality acrylic primer to the wall before using any adhesive. Choose a primer that's best suited for your wall type. Allow the primer to dry completely, typically 24–48 hours, before moving on to the next step. In the US we recommend Roman Pro 977 Ultra Prime.

2. PREPARING WALLCOVERING

- Use the following tools for precise cutting:
 - A large table
 - A long, rigid metal ruler
 - A cutter and fresh cutting blades
- Cut the white margins very straight to ensure perfect, almost invisible joints. Be careful not to scratch the wallcovering surface during manipulation of the large panels.
- For very dark wallcoverings, apply a matching dark color along the edges of the paper with a thin brush. This prevents visible white seams after hanging.

3. HANGING COATED TEXTILE WALLPAPER

- Apply adhesive only to the wallcovering. In the US we recommend Roman Pro-880 Ultra Clear Strippable or Roman Pro-774 Clay Strippable adhesives.
- Once fully pasted allow the panels to set, or book, for up to 20 minutes before installing the panel to the wall.

4. SMOOTHING THE WALLPAPER & JOINING PANELS

- Use a flat brush or a heavy rubber roller to smooth the wallcovering onto the wall, moving from the inside to the outside of the panel. Avoid using plastic scrapers, as they may damage the printed surface.
- While the adhesive is still wet, push the edges of two connecting panels together to eliminate visible seams. Proper hanging should result in completely undetectable seams.
- Use a clean utility knife to trim the panel to match the ceiling and baseboard. Clean the blade tip after each cut.