

Hanging Instructions for Wallpaper

Scrubbable Non-Woven

untrimmed

1. SURFACE PREPARATION

- Apply a high-quality acrylic primer to the surface before applying adhesive. Allow the primer to dry thoroughly for optimal results.

2. PREPARING WALLPAPER

- Use the following tools for precise cutting:
 - A large table
 - A long, rigid metal ruler
 - A cutter and fresh cutting blades
- Cut the white margins very straight to ensure perfect, almost invisible joints. Be careful not to scratch the wallpaper surface during manipulation of the large panels.
- For very dark wallpapers, apply a matching dark color along the edges of the paper with a thin brush. This prevents visible white seams after hanging.

3. HANGING SCRUBBABLE NON-WOVEN WALLPAPER

- This wallpaper, noted for its rigidity and pleasant texture, is easy to hang. Select an adhesive specifically designed for non-woven wallpaper. Apply adhesive only to the wall, not to the wallpaper.
- Avoid getting adhesive on the printed surface. If the adhesive contacts the surface, gently dab it off with a dry cloth and allow it to dry.

4. SMOOTHING THE WALLPAPER & JOINING PANELS

- Use a flat brush or a heavy rubber roller to smooth the wallpaper onto the wall. Avoid using plastic scrapers, as they may damage the printed surface.
- While the adhesive is still wet, push the edges of two connecting panels together to eliminate visible seams. Proper hanging should result in completely undetectable seams.